1 Keep for future reference. Log on to www.lotsofbabies.com for instruction videos

Lotsofbabies Lotsofbabies Ltd

58 Cavendish Road, Salford, Greater Manchester M7 4NQ 0161 740 9979





Instruction Leaflet

Single and Double Toddler Seat for the T3 and T4 Pushchair

WARNING

- Never leave your child unattended
- Ensure that all the locking devices are engaged before use.
- To avoid injury ensure that your child is kept away when unfolding and folding this product.
- Do not let your child play with this product.
- This product is not suitable for running or skating
- Always use the restraint system
- Check that the seat unit or car seat attachment devices are correctly engaged before use

Suitable for children up to 15kg.

Suitable for children over 6 months old

Compatible with Lotsofbabies T3 Pushchair.

SAFETY INSTRUCTIONS

Engage the parking brake when placing and removing children.

Do not overload the shopping basket, maximum 3kg.

Any load attached to the handle and/or on the back of the backrest and/or on the sides of the vehicle will affect the stability of the vehicle.

Regularly inspect straps and joints for wear and tear. Use WD40 on swivels, joints and points of contact. Wash fabrics with water and upholstery foam cleaners (test first for suitability) do not soak.

Only put the number of children in the pushchair that it is made to accommodate.

Do not use accessories that have not been approved by Lotsofbabies Ltd.

2 Keep for future reference. Log on to <u>www.lotsofbabies.com</u> for instruction videos Only replacement parts supplied or recommended by Lotsofbabies Ltd shall be used.

ASSEMBLY



Open seat frame and slide front tubes into housing. Push firmly until spring button locks.





Pull fabric tab to reveal the slot for the hood clip. Push home firmly.

ATTACHMENT





Push and lock mouldings at end of tubes into the housing on the pushchair frame.



Firmly fasten the strap at the front of the seat to the 'D' ring under the footplate.



For the **Double Seat**, pass the long straps Under the footplate and clip together. Adjust so it is a firm fit.

HARNESS ADJUSTMENT





Push pronged clips into the housing to lock.







Adjust sliders for a firm fit.



Harness 'D' rings are fitted at the ends of each waist strap for the attachment of an additional harness.